



Infotainment/MMI

Quick Reference Guide



▲ MMI Terminal

▲ FM/AM

▲ CD - NAME ▼

Dear driver,

This quick reference guide highlights the most important operating procedures and functions of the Multi Media Interface (MMI).

However, it does not replace the Owner's Manual. Therefore, it is necessary that you also familiarize yourself with the important contents of the Owner's Manual.

We hope you enjoy driving your new Audi.

AUDI AG



Switching MMI on and off

Switching on and off automatically: The MMI is switched on automatically when the ignition is turned on. When the ignition key is removed the MMI switches off automatically.

Switching on and off manually:

If necessary, the MMI can be switched off by pressing the ON/OFF knob and holding it until the MMI switches off. If the MMI was switched off manually, it can be switched on again using the ON/OFF knob. Note that a quick press mutes the audio.



Tip
When you turn the ON/OFF knob, the volume is increased/decreased.

MMI Terminal

The electronic vehicle equipment (e.g. radio, navigation system, etc.) can be operated easily using the MMI terminal. Select the desired function by clicking on the respective main function button:


- FM ^(FM) AM (Radio)
- CD
- NAME (Directory)
- TEL (Cell phone package)
- NAV (Navigation)
- INFO (Information service)
- CAR (Vehicle settings)
- SETUP (Basic settings)

Note: The climate control system is adjusted using the ss-climate control system controls.

⚠ WARNING!

- Distraction causes accidents:**
- Never enter data while driving!
 - Obey traffic laws & road signs!
 - Refer to the Owner's Manual!

Operating MMI




FM ^(P) AM (Radio)

Example: Adjust bass


1. Press the "FM ^(P) AM" function button.



2. Press the "Sound" control button.



3. Turn to select "Bass" and press to enter.




4. Turn to tune "Bass" and press to store in memory.



5. Press RETURN to go to the previous menu or press the "RADIO" function button to return to main menu.

FM ^(P) AM (Radio)

Menu structure



Press SETUP for the selected RADIO function.

- RADIO setup menu (Satellite Radio)**
- Sort station by
 - Station info
 - Category filter
 - Receiver serial number
 - Delete radio presets

Press SETUP for the selected RADIO function.

- RADIO setup menu (FM/AM)**
- Station reception
 - Station display¹⁾
 - Previous stations¹⁾
 - Delete previous stations¹⁾
 - Delete radio presets

¹⁾ Only for FM operation

Tip
The MMI can be muted by briefly pressing the ON/OFF knob, so that you will not be disturbed, for example, by radio music or the CD player. Press or rotate the ON/OFF knob to cancel the muting. Muting occurs automatically when a telephone call is being made. If the CD function is active, CD playback is stopped while the mute function is activated.


CD

Example: Select CD


1. Press the "CD" function button.



2. Press the "CD list" control button.



3. Turn to select the desired CD.




4. Press to enter.



Note: The track list of the selected CD will be displayed in the main menu.

CD

Menu structure



Tip
By pressing the arrow keys you can, for example, select the next or previous station on the radio or the next or previous title of the CD that is playing.




NAME (Directory)

Example: Generating new entries in the directory


1. Press the "NAME" function button.




2. Press the "Edit" control button and select "New entry" by pressing the control knob.



3. Select "Last name" by pressing the control knob.



4. Turn the speller to the desired character and press to enter. When ready turn the speller to "OK" and press to enter.




5. Afterwards, fill in all of the desired entry fields as described.

6. Press RETURN or press the "NAME" function button to return to main menu.

NAME (Directory)

Menu structure



Tips

Telephone numbers and navigation destinations can also be stored in directory entries.

When entering characters using the speller, enter just enough characters until the searched name appears in the edit list. Selection of the edit list can be performed by turning to and pressing "LIST".

Multi-function steering wheel operating elements

The multi-function steering wheel enables quick and easy operation of selected systems on the MMI.

MODE button ② (Select main function)

Press the MODE button until the desired main function is seen in the display of the instrument cluster between the tachometer and speedometer.

Left thumbwheel ①

Roll the thumbwheel until the desired menu item is tagged. The selection is confirmed by pressing the thumbwheel. Note that this thumbwheel controls only the radio, CD and telephone function.



Talk Button ③

Right thumbwheel ④

Roll the thumbwheel to regulate the volume. Press the thumbwheel to repeat the last navigation voice message.

Speech dialog system

The speech dialog system allows operation of the following functions by voice commands:

- RADIO
- CD changer
- NAME (Directory)
- TEL (Cell phone package)
- NAV (Navigation system)

To activate the speech dialog system press the Talk Button ③ on the multi-function steering wheel. The dialog begins after you hear the chime <Beep>.

A help function is integrated into the speech dialog system, which is available to you in all functions. If you do not know the desired command, simply say **HELP**. The system will then name all of the possible commands.

To deactivate the system press the Talk Button ③ again until you hear the announcement <Cancel>, or simply say **CANCEL**.

TEL (Cell phone package)

Example: Select telephone number

Note: The possible MMI telephone functions are dependent upon the cell phone that is used.


1. Press the "TEL" function button.



2. Enter the desired telephone number by turning and pressing the speller.





3. Select "OK" using the speller, or press the "Dial" control button.



TEL (Cell phone package)

Menu structure



INFO (Information service)

1. Press the "INFO" function button.



2. Turn the knob to scroll through the info, if necessary.





3. Press the "NAV" function button for example, to return to the navigation main menu.


NAV (Navigation)

Example: Enter destination


1. Press the "NAV" function button.



2. Turn to select "City" and press to enter.




3. Turn the speller on the desired character and press to enter.




4. When "OK" appears, turn the speller on "OK" and press to enter.



5. Turn to select "Input street name" and repeat the input processes.



6. Select "End entry".



7. Select "Start route guidance".

NAV (Navigation)

Menu structure

Previous destinations

Top categories

Load from directory

Store in directory

Edit directory

Load route

Store route

Delete route

Memory

Nav-Info

Destination/stopover data

Estimated time of arrival

Distance

Location data

Telephone number for special destinations

Geographic destination data (latitude, longitude)

Geographic location of your vehicle (latitude, longitude, altitude)

Received satellites



Route with stopover

Route without stopover

Route list

Route criteria

Avoid route from here



Route

Map

Zoom

Map side menu



Press SETUP for the selected NAVIGATION function.

NAVIGATION setup menu

Map scheme

Orientation

Intersection zoom

Map view

Map content

Voice guidance

Altitude display

Delete previous destinations

Enter NAV start location

Demo mode

Version information

Tips

If the MMI display shows the message **<Please check navigation DVD>** it may be possible that the navigation DVD is smudged and can no longer be read. Clean the DVD by wiping from the inside to the outside with a soft, lint-free cloth.

If no display of the destination entry screen with a final destination (navigation main menu) appears when calling up the NAV main function, the **<Route with stopover>** function is activated. Press the **<Route>** control button and confirm the menu item **<Route without stopover>** by pressing the control knob. The entry screen with direct input of the final destination will be displayed.

The Navigation system can only calculate a route if the details regarding the local situation are available. If a detour is not possible, the Navigation system will not offer an alternative route, even though you have entered settings in the menu path **<NAV>Route>Avoid route from here>**.

CAR

Example: Display vehicle ID number

1. Press the "CAR" function button.



2. Press the "Systems" control button.



3. Turn the speller to "Vehicle ID number" and press to enter.



4. The vehicle ID number will be displayed.

5. Press RETURN to go to the previous menu or press the "CAR" function button to return to the main menu.

CAR


Menu structure




SETUP

Example: Select language

1. Press the "SETUP" function button from any main function (i.e. RADIO).




2. Press the "Settings" control button.



3. Confirm by pressing "Menu language".




4. Turn to select the desired language and press to enter.



5. Press RETURN to go to the previous menu or press the "RADIO" function button, for example, to return to the main menu.

SETUP

Menu structure



Tip

By pressing the SETUP button, an additional SETUP menu can be called up from **any main function** (i.e. radio).

© 2006 AUDI of America, Inc

Audi is constantly improving their products. Modifications in shape, equipment and technology are possible. No legal commitment is therefore implied by the details, illustrations and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, are not permitted without written permission of Audi of America, Inc. All rights are expressly reserved by Audi of America, Inc. Subject to modification without notice. Printed in Germany. Concept and design: Pfriemer GmbH.